## Fujitsu Kagami Overview

### Main Screen Functions

- 1. Current room temperature
- 2. View and set temp
- 3. View and set mode
- 4. View and set fan speed
- 5. Settings
- 6. Mode indication light
- 7. Power unit on and off

## System Modes

To switch between modes, swipe to the left once on the default screen and make your selection

## Symbol Name Indicator colour Cool Blue Dry\* Green Heat Red Minimum Red Heat\*\* Auto Purple Fan White

# 2 3 4 5 10:20PM 1 80 82 81 SET TEMP. 80 2 79 78

## Adjusting the temperature

To adjust the temperature up or down, simply tap the center of the screen and slide up or down.

If you are in "Auto" mode, tap a second time to switch the set point of the opposite mode.

## **Fan Modes**

To switch fan speed, swipe left twice on the default screen

Fan speeds may be different depending on the indoor model that the thermostat is controlling. If you choose high, medium, low, or quiet fan settings, this will run the fan on the chosen setting when there is a call for heating and will turn off the fan when there is no call for heat. When in cooling mode, the fan will run 24/7 on the chosen speed setting.

<sup>\*</sup>Dry mode acts to remove moisture from the air in your home. Not recommended for our region.

<sup>\*\*</sup>Minimum Heat mode should be used only if you plan to leave for an extended period of time in the winter months